

## MiVOICE CONFERENCE/VIDEO PHONE - QUICK REFERENCE GUIDE



### Activating the HDMI Display

- If the screen is dark, press Home
- Ensure that the HDMI device is turned on.

### Adjusting the Camera for a Video Call

- Before a video call, tap on the display.
- Tap to turn on your local camera.
- Check that the camera is positioned at the best angle.

**NOTE:** For a MiVoice Conference Phone, the Camera Control icon and Camera Status icons are not available.

### Adding Calls to a Conference

An incoming call appears on a conference avatar.



- Tap to answer the call. You can talk with the caller.

The first call is automatically added to the conference.  
When subsequent calls arrive:

- Tap to talk with the caller, and tap to add the caller to the conference.
- You can tap to ignore the call.

### Making a Call

#### Using the Keypad or Redial

- Tap or and enter a number.
- Or press and select a number from the Redial list.
- Press .
- Tap to open contacts.
- Select a contact to call.

#### Using Contacts

- Tap to open contacts.
- Select a contact to call.

If your MiVoice Video Phone and the external party is video-enabled, a video connection is established.

### Displaying a Presentation

- On the screen, tap to launch an application for your presentation.
- Select the app you wish to use.

The external parties connected via video will automatically see the presentation.

### Using the Presentation Controls

When the App is displayed, you will see the Presentation Controls:



The window closes several seconds after it is displayed. It also indicates whether you are sharing or not sharing a presentation. These controls allow you to do the following:

- Tap to open or close the Presentation Controls.

### Using Mitel MiCollab Conference

You can easily launch MiCollab Conference from the phone.

- Tap on the touch screen.
- 2. Tap MiCollab Conference .
- 3. Select either Add Server and add a server if necessary, or select an MCA Server from the list by tapping on the server name in the upper left corner.
- 4. Enter access code (using the keyboard).
- 5. Tap to join the conference.
- 6. Tap for more information.

### Using Camera Control


Camera Control lets you change the camera status at any point during a call. The options available depend on the state of the call.

- Tap on the display or from during a presentation to change the camera status.
- Press the desired icon: Turn Camera On or Off, Turn Self View On or Off, or Turn Picture-in-Picture (PIP) On or Off.

### Using Display Mode

After you have launched an App, Display Mode lets you choose what the participants will see. The options available depend on the state of the call.

- Tap to select what participants will see on the HDMI display.
- Press the desired icon: App Only, App + Video, Video Only, or Nothing.



If you wish to quickly display nothing on the HDMI monitor for confidentiality reasons:

- Press and select Nothing .

### Using the Browser

- Tap on the touch screen and select Browser.
- Navigate to your web-based email, Google accounts, cloud-enabled documents, web-based content, and so forth.

### Using Picsel® SmartOffice™

- Insert your USB flash drive or micro SD card, if needed.
- Tap on the touch screen and select or .
- Navigate to the document you wish to use in Dropbox™, Google® Docs or Box.net, or to the file on the flash drive or SD card.

## MiVOICE CONFERENCE/VIDEO PHONE - QUICK REFERENCE GUIDE



### Using Remote Desktop (RDP)

1. Tap  on the screen.
2. Tap **RemoteRDP** for Remote Desktop.
3. If your computer name has not been preset by the administrator, tap the Host/IP field and enter your computer name or IP address.

**NOTE:** You can save your computer name/IP address to a USB flash drive for future use.

4. Press **Connect** and login to your remote computer.
5. Navigate to the application you wish to use on your desktop.
6. Use the external mouse and keyboard to navigate the display.

### Hold

- Tap  for the individual participant.
  - Tap again to retrieve the call or press the flashing red ring around the conference avatar.
- To put the entire conference on hold, place each party on hold.
- In a video call, video is blocked in both directions.

### Muting a Conference Call

- Press Mute .
- You will see a red light above the mute button when muted.
- Press again to unmute.

If desired, turn your video off by pressing  and then .

### Ending the Session and Cleaning Up

1. Press End Conference .
  2. Press Close All Apps .
- Press **Yes** when prompted by the dialog "Would you like to close all applications, clear login credentials and browser history?" This will clear personal information.

### Cleaning the Display Screen

1. Press Menu  then Settings .
2. Tap **Clean Mode**.
3. When the screen is clean, hold  for 3 seconds to exit Clean Mode.

### Brightness

1. Press Menu .
2. Press Settings .
3. Tap **Brightness** and drag the slider to the desired brightness.
4. Press **OK**.

### Adjusting the In-Call Volume

- Press the volume button  during a call.

### Adjusting the Ringer Volume

- Press the volume button  during ringing.

### Function Keys

	Home - Go to the Home screen
	Menu - Display the Menu bar
	Back - Go back one menu or to the previous screen
	Mute - Turn off the microphone
	Volume - Increase or decrease the volume
	Help - Access help for the active screen
	Present - Open Contacts App to select a contact to dial.
	Dial - Launch a shared app
	Close All Apps and delete data
	Settings - Select what participants will see

### App, Display Mode, and Camera Controls

	Display Mode - Open the keypad to dial an audio call
	Camera Control - Phone and camera - Open the keypad to make an audio/video call
	Conference Avatar - Open Contacts App to select a contact to dial.
	Message and Action Area - Launch a shared app
	Help - Close All Apps and delete data
	Settings - Turn camera control on
	Help - Select what participants will see